

FIG. 3

| | VOLUME SPACE - | | | | | | | | |
|------------------------------|----------------|------------|------------|--|--|--|--|--|--|
| VOLUME AND FILE STRUCTURE | DVD-VIDEO DATA | ENAV FILES | OTHER DATA | | | | | | |

FIG. 4




FIG. 5




FIG. 6




FIG. 7

<STARTUP.MLS>

FIG. 8

<STARTUP.MLS>

FIG. 9

| SYSTEM PARAMETER | MEANINGS |
|---------------------|---|
| 0 | Menu Description Language Code(M_LCD) |
| 1 | Audio stream number(ASTN) for Title Domain(TT_DOM) |
| 2 | Sub-picture stream number(SPSTN) and On/OFF flag for TT_DOM |
| 3 | Angle number(AGLN) for TT_DOM |
| 4 | Title number(TTN) for TT_DOM |
| 5 | VTS Title number(VTS_TTN) for TT_DOM |
| 6 | Title PGC number(TT_PGCN) for TT_DOM |
| 7 | Part_of Title number(PTTN) for One_Sequential_PGC_Title |
| 8 | Highlighted Button number(HL_BTNN) for Selection state |
| 9 | Navigation Timer(NV_TMR) |
| 10 | TT_PGCN for NV_TMR |
| 11 | Player Audio Mixing Mode(P_AMXMD) for Karaoke |
| 12 | Country Code(CTY_CD) for Parental Management |
| 13 | Parental Level(PTL_LVL) |
| 14 | Player Configuration(P_CFG) for Video |
| 15 | P_CFG for Audio |
| 16 | Initial Language Code(INI_LCD) for Audio Stream(AST) |
| 17 | Initial Language Code extension(INI_LCD_EXT) for AST |
| 18 | INI_LCD for Sub-picture Stream(SPST) |
| 19 | INI_LCD_EXT for SPST |
| 20 | Player Region Code |
| 21 | Initial Language Code(INI_LCD) for ENAV Application |
| 22 | |
| 23 | |

FIG. 10

| <u>b15</u> | b14 | b13 | b12 | b11 | b10 | b9 | b8 | | |
|------------|-----|-----|-----|-----|-----|----|----|--|--|
| RESERVED | | | | | | | | | |
| | | | | | | | | | |
| <u>b7</u> | b6 | b5 | b4 | b3 | b2 | b1 | b0 | | |
| INI-LCD | | | | | | | | | |
| | | | | | | | | | |

FIG. 11

